


# Sawgrass Printers

## SPM Print Setup Guide: Photoshop CS6-CC

**IMPORTANT:** Before proceeding, ensure that the Sawgrass Print Manager and the Sawgrass driver have been installed. For assistance with installation, refer to the Installation Guide.

### Adobe Photoshop Workspace Setup

- 1) Begin by opening Adobe Photoshop. In the menu bar, click **Edit > Color Settings** (see *FIGURE 1*).



**FIGURE 1**

# Sawgrass Printers

## SPM Print Setup Guide: Photoshop CS6-CC

- In the Color Settings window that opens, match your settings to those shown below (see *FIGURE 2*). Once settings are changed, click Save.




FIGURE 2

- Enter a name for the setting and click Save (see *FIGURE 3*).





FIGURE 3

# Sawgrass Printers


## SPM Print Setup Guide: Photoshop CS6-CC

- 4) If creating a new document, go to **File > New** (see *FIGURE 4*).



**FIGURE 4**

- 5) Select the dimensions then make sure the resolution is set at 300 dpi and the Color Mode is RGB. The bit number can be changed up to 32 bit however, the higher the bit the more memory it takes the computer to process (See *FIGURE 5*).




**FIGURE 5**

# Sawgrass Printers


## SPM Print Setup Guide: Photoshop CS6-CC

- 6) If opening an existing document, you may get a message such as the one below which indicates that the file was created with a different profile. Select **Convert document's colors to the working space**. (see *FIGURE 6*).



**FIGURE 6**

- 7) Go to **Image > Mode** and make sure the color mode is set on **RGB Color** (see *FIGURE 7*).



# Sawgrass Printers

## SPM Print Setup Guide: Photoshop CS6-CC

### Printing using the Sawgrass Print Manager

- 1) Unfortunately, on a Mac you cannot print directly to the SPM from Photoshop. You will have to save the artwork as either a .jpg, .png or .pdf file.
- 2) After the file is saved, go to the top toolbar and click on the **PM** icon and select **Open Local File**. (see *FIGURE 1*). If the icon is not there, then go to Applications and double click the Virtuoso Print Manager.




FIGURE 1

- 3) Locate the file that needs to be printed (see *FIGURE 2*).




FIGURE 2

# Sawgrass Printers

## SPM Print Setup Guide: Photoshop CS6-CC

- 4) SPM window will appear. If you have more than one printer be sure to select the correct one from the dropdown. Then select the **substrate**, **paper type** and **tray**. You can also set the print quality (most of the time **High Quality** will be used. If sublimating onto the front of the substrate, you will leave the **Mirror** option checked. If sublimating onto the back of the substrate (usually glass or acrylic) then uncheck it (see *FIGURE 3*).




FIGURE 3

- 5) Under the **Jobs** tab is where the number of copies can be entered. (see *FIGURE 4*).





FIGURE 4

# Sawgrass Printers

## SPM Print Setup Guide: Photoshop CS6-CC

- 6) Under the **Color** tab, you can make color adjustments. Under the **Color Mode** there are two options available. **Vivid** setting (for logos or vector art) and **Photographic** (for photos). The Palette section will replace spot colors in the design with **ColorSure** colors. (see *FIGURE 5*).



**FIGURE 5**

- 7) Once all options are selected click **Print**.