

Configuration Guide: Adobe Illustrator CS/CC (Windows OS)

Illustrator Color Setup

1. Open Adobe Illustrator. In the menu bar, click **Edit > Color Settings**. See Figure 1.




FIGURE 1

- In the Color Settings window, select **Sawgrass_sRGB** in the settings dropdown and confirm that your settings match those shown below, and click **OK**. See Figure 2.




FIGURE 2

- In the menu bar, click **File > New**. See Figure 3.




FIGURE 3

4. In the **New Document** window, match the settings below. See Figure 4.




FIGURE 4

- a. Click the down arrow next to **Advanced**
- b. Color Mode: **RGB**
- c. Raster Effects: **High (300 ppi)**
- d. Preview Mode: **Default**
- e. Click **OK** to save your changes and continue

5. When opening or importing images in Illustrator, you may encounter the following warnings. For the **Missing Profile** instance (5a), select “**Assign current working space:sRGB IEC61966-2.1**” and click **OK**. For the **Embedded Profile Mismatch** instance (5b), select “**Convert document’s colors to the working space**” and click **OK**.




FIGURE 5b




FIGURE 5a

6. Previously saved files or imported files may retain their previous settings. To ensure that RGB color mode has been selected: In the menu bar, click **File > Document Color Mode > RGB Color**. A check mark should be visible beside **RGB Color**. See Figure 6.




FIGURE 6

Illustrator Print Setup

7. With the correct color settings entered, you are now ready to print. In the Menu Bar, click **File > Print**. In the Print window, match your settings to those shown below. See Figure 7.





FIGURE 7

- a. Printer: **PowerDriver-v4 SG400/800 (US)** or **Sawgrass Print Manager**
- b. Size: **Defined by Driver**
- c. Click **Color Management** to view the color management settings

8. In the **Color Management** area, match your settings to those shown below.



See Figure 8.

FIGURE 8

- a. Color Handling: **Let Illustrator determine colors**
- b. Printer Profile: **sRGB IEC61966-2.1**
- c. Rendering Intent: **Perceptual**
- d. Click **Print** when you are ready to print your image

Illustrator setup is now complete. Remember to, if necessary, convert imported graphics to the sRGB working space, ensure the RGB color mode is checked and select the PowerDriver-v4 SG400(US) or SPM each time you print.